

Security Controller Keyboard



Key Features

- PTZ of dome cameras with joy stick
- Jog shuttle dial for FF/REW/Playback/Frame by frame of images
- LCD display for DVR status
- Split screen buttons
- Monitor A/B selection
- Triplex playback control

Designed specifically for the DX-TL5000U, DX-TL4700U Series and DX-TL4500U DVR Series, the DX-KB5UE Security Controller Keyboard provides all the features necessary for the security professional for quick and easy control of the digital video recorder. With its sleek ergonomic design, the DX-KB5UE is packed with features and yet, intuitive in layout for quick access to DVR control functions.

Key features include a joy stick for PTZ control of various dome cameras, LCD display to show status of DVR, jog/shuttle dial for FF/REW, frame by frame of images and multiplexer display buttons. Connection is simple via RS-485 to the DVR. The DX-KB5UE comes with its own AC power adapter.

Powerful in features and yet easy to use, the DX-KB5UE makes control of Mitsubishi DVRs effortless and simple.



Rear panel connections

Specifications

AC Adapter	Class	AC adapter
(DX-EP1E)	Rated power supply	100-240 V AC; 50/60 Hz
	Maximum current	1.0 A
	Rated output	DC 9 V, 1.67 A
	Dimensions (W x D x H)	2.2 x 1.0 x 3.3" (56 x 25.5 x 85 mm) (excluding the cord)
	Weight	.66 lbs. (0.3 kg) (including the AC adapter and cord)
DX-KB5UE	Rated power supply	DC 9 V
	Rated input	0.5 A
	Operation temperature	41 °F to 104 °F (5 °C to 40 °C)
	Relative humidity	Max. 80 %
	Altitude	Max. 2000 m
	Dimensions (W x D x H)	14.4 x 7.9 x 3.7" (356 x 201 x 94 mm)
	Weight	4.4 lbs. (2.0 kg)
	Control terminal	RS-485 port RS-485 Output RJ-11 Serial port RS-232C D-SUB 9 pin
Accessories	1 AC power cord/AC adapter (DX-EP1E)	

System Structure

